



INA3608

1U Rackmount Network Appliance

User's Manual

Version 1.0
(December 2023)

Copyright

© 2023 IBASE Technology, Inc. All rights reserved.

All rights reserved. No part of this publication may be reproduced, copied, stored in a retrieval system, translated into any language or transmitted in any form or by any means, electronic, mechanical, photocopying, or otherwise, without the prior written consent of IBASE Technology, Inc. (hereinafter referred to as “IBASE”).

Disclaimer

IBASE reserves the right to make changes and improvements to the products described in this document without prior notice. Every effort has been made to ensure the information in the document is correct; however, IBASE does not guarantee this document is error-free. IBASE assumes no liability for incidental or consequential damages arising from misapplication or inability to use the product or the information contained herein, nor for any infringements of rights of third parties, which may result from its use.

Trademarks

All the trademarks, registrations and brands mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective owners.

Compliance



This product has passed CE tests for environmental specifications and limits. This product is in accordance with the directives of the European Union (EU). If users modify and/or install other devices in this equipment, the CE conformity declaration may no longer be valid.



This product has been tested and found to comply with the limits for a Class A device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications.

WEEE



This product must not be disposed of as normal household waste, in accordance with the EU directive for waste electrical and electronic equipment (WEEE - 2012/19/EU). Instead, it should be disposed of by returning it to a municipal recycling collection point. Check local regulations for disposal of electronic products.

Green IBASE



This product complies with the current RoHS directives, which restrict the use of the following substances in concentrations not to exceed 0.1% by weight (1000 ppm) except for cadmium, limited to 0.01% by weight (100 ppm).

- Lead (Pb)
- Mercury (Hg)
- Cadmium (Cd)
- Hexavalent chromium (Cr6+)
- Polybrominated biphenyls (PBB)
- Polybrominated diphenyl ether (PBDE)

Important Safety Information

Carefully read the following safety information before using the device.

Setting up your system:

- Put the device horizontally on a stable and solid surface.
- Slots and openings on the chassis are for ventilation. Do not block or cover these openings. Make sure you leave plenty of space around the device for ventilation. NEVER INSERT OBJECTS OF ANY KIND INTO THE VENTILATION OPENINGS.
- Use this product in environments with ambient temperatures between 0°C and 40°C.
- AVOID PLACING THIS DEVICE IN ENVIRONMENTS WHERE THE STORAGE TEMPERATURE MAY FALL BELOW -20°C OR EXCEED 70°C, as this could damage the device. The device must be used in a controlled environment.

Care during use:

- Do not place heavy objects on the top of the device.
- Make sure to connect the correct voltage to the device. Failure to supply the correct voltage could damage the unit.
- Do not walk on the power cord or allow anything to rest on it.
- If you use an extension cord, make sure the total ampere rating of all devices plugged into the extension cord does not exceed the cord's ampere rating.
- Do not spill water or any other liquids on your device.
- Always unplug the power cord from the wall outlet before cleaning the device.
- Only use cleaning agents with a neutral pH level to clean the device.
- Vacuum dust and particles from the vents by using a computer vacuum cleaner.



CAUTION

There is a danger of explosion if the lithium-ion battery is replaced with an incorrect battery. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions. Under no circumstances should the Lithium battery cell be shorted; otherwise the battery cell may heat up or cause potential burn hazards.

Warranty Policy

- **IBASE standard products:**

24-month (2-year) warranty from the date of shipment. If the date of shipment cannot be ascertained, customers can use the product serial numbers to approximate the shipping date.

- **3rd-party parts:**

12-month (1-year) warranty from delivery for the 3rd-party parts that are not manufactured by IBASE, such as CPU, memory, HDD, power adapter, panel and touchscreen.

* PRODUCTS, HOWEVER, THAT FAIL DUE TO MISUSE, ACCIDENT, IMPROPER INSTALLATION, OR UNAUTHORIZED REPAIR WILL BE TREATED AS OUT OF WARRANTY, AND CUSTOMERS SHALL BE BILLED FOR REPAIR AND SHIPPING CHARGES.

Table of Contents

Chapter 1	General Information	1
1.1	Introduction	2
1.2	Features.....	2
1.3	Packing List	3
1.4	INA3608 Specifications	4
1.5	Product View.....	5
1.6	Dimensions	8
Chapter 2	Hardware Configuration	10
2.1	Installations	11
2.1.1	Configuration inside	11
2.1.2	Desktop Installation	12
2.1.3	Rack Mount Installation	12
2.1.4	System Installation	13
2.1.5	Network Module.....	13
2.1.6	Redundant Power Supply Unit.....	13
2.1.7	Memory Module.....	14
2.1.8	HDD Installation and Replacement	15
2.1.9	M.2 Card Installation/Replacement	16
2.2	Setting the Jumpers	17
2.3	Jumper & Connector Locations on Motherboard	18
2.4	Jumpers Quick Reference.....	19
2.4.1	JP1: M.2 PCIE / M.2 Select	19
2.4.2	JP3: Clear ME Register	20
2.4.3	JP4: Flash Security.....	21
2.4.4	JP5: Clear CMOS Content.....	22
2.4.5	JP6: SATA DOM Power Select.....	23
2.4.6	JP7: AT & ATX Mode.....	24
2.4.7	JP9:	25
2.4.8	SW1: System Reset.....	25
2.4.9	SW2: NMI (Non-Maskable Interrupt).....	26
2.5	Connectors Quick Reference	27
2.6.1	BT1: Battery (CR2032)	28
2.6.2	CN1: Display Port	28
2.6.3	CN2, CN3, CN6: SATA Power Connector.....	29
2.6.4	CN4: SATA DOM Port	29
2.6.5	CN5, CN7: SATA III Port	30

2.6.6	CN11: LCM Connector	30
2.6.7	FAN1, FAN2, FAN3, FAN4: Fan Power Connector	31
2.6.8	J1, J13: External Power Switch Connector	31
2.6.9	J2: Factory Use Only	32
2.6.10	J3: .2 M2280 Slot.....	32
2.6.11	J4, J5: DDR5 Memory Slot	33
2.6.12	J11: MINI_SAS_LED#	33
2.6.13	J12: Mini SAS Connector.....	34
2.6.14	J14, J6: ATX Power Connector.....	34
2.6.15	PCIE1, PCIE2: PCIE Connector	35
2.6.16	U12: CPU Slot	35
Chapter 3	BIOS Setup	36
3.1	Introduction	37
3.2	BIOS Setup	37
3.3	Main Settings	38
3.4	Advanced Settings	38
3.5	Platform Configuration	49
3.6	Socket Configuration.....	51
3.7	Server Management.....	52
3.8	Security Settings	54
3.9	Boot Settings.....	55
3.10	Save & Exit Settings.....	56
3.11	Server Management Settings	57

Chapter 1

General Information

The information provided in this chapter includes:

- Features
- Packing List
- Optional Accessories
- Specifications
- Product View
- Dimensions

1.1 Introduction

The INA3608 stands as a versatile and high-performance network appliance catering to diverse networking needs across industries, delivering reliability, scalability, and efficient operation in various applications. At its core lies the formidable Intel® Raptor Lake Core i Series Processor coupled with the PCH R680E chipset, ensuring powerful and efficient performance for demanding networking tasks. Accompanied by 2x DDR5 4800MHz UDIMM (ECC) slots, this appliance offers enhanced memory capabilities.

This network appliance is designed to optimize connectivity with an array of ports, including 4x 2.5GbE RJ45 ports with 1 pairs bypass on board, along with 4x Gbe SFP and 2x 10GbE SFP+ on board. Additionally, the appliance boasts an optional NIC slot, allowing for further customization and expansion to meet specific networking requirements. The inclusion of 1x SATA/NVMe M.2 and 1x PCIe 5x8 expansion slot further enhances storage and expansion capabilities. With its 600W AC redundant power supplies, the INA3608 ensures uninterrupted operation and reliability in mission-critical environments.

Applications for the INA3608 span across various industries, making it a versatile and adaptable solution for:

- Enterprise Networking
- Telecommunications
- Cybersecurity

1.2 Features

- Intel Raptor Lake Core i Series Processor with PCH R680E
- 2x DDR5 4800MHz, UDIMM (ECC)
- 4x 2.5GbE RJ45 with 1 pairs bypass on board
- 4x Gbe SFP ports on board
- 2x 10GbE SFP+ ports on board
- Optional NIC slot
- 1x SATA/NVMe M.2
- 1x PCIe 5x8 expansion slot
- 600W AC redundant power supplies

1.3 Packing List

Your product package should include the items listed below. If any of the items below is missing, contact the distributor or the dealer from whom you purchased the product.

Models with a single PSU:

- INA3608 x 1
- 500W ATX Single Power Supply x 1
- Power Cord (180 cm) x 1
- Console cable x 1
- Rack Mount Bracket x 2
- Heatsink x 1

Models with 1+1 redundant PSU:

- INA3608 x 1
- 600W 1+1 Redundant Power Supply Unit x 1
- Power Cord (180 cm) x 2
- Console cable x 1
- Rack Mount Bracket x 2
- Heatsink x 1

Models with 1+1 redundant PSU:

- INA3608 x 1
- 450W 1+1 Redundant Power Supply Unit x 1
- Power Cord (180 cm) x 2
- Console cable x 1
- Rack Mount Bracket x 2
- Heatsink x 1


1.4 INA3608 Specifications

CPU	13 th Generation Intel Core i Processors LGA1700 Socket
Chipset	Intel® PCH R680E
Memory	2x DDR5 UDIMM up to 4800 MT/s, up to 128 GB
Ethernet	4x 2.5Gbe RJ45 ports (Intel i226V) 4x 1Gbe SFP ports (Intel i210IS) 2x 10Gbe SFP+ (Intel X710)
Bypass	1 pair control by MCU
Expansion	1 PCIe Gen5 x8 (for SSL card) 1 PCIe Gen5 x8 (for IBN Module)
IPMI	N/A
Storage	1x 2.5" internal HDD/SSD 1x SATA DOM 1x 2280 M.2 slot
TPM	TPM 2.0
I/O	1x LCM 3x LED (Status/HDD/Power) 1x RJ45 console 2x USB 3.0 1x Reset Button 1x NMI Button
Power Supply	600W/450W 1+1 Redundant Power Supply 500W Single Power Supply
Dimensions	438(W) x 420(D) x 44(H) mm ± 0.3mm
Weight	15 kg
Temperature	• Operating: 0°C~ 50°C • Storage: -20° ~ 70°C
Humidity	10% ~ 90% at 45°C (non-condensing)
Vibration Protection	• Operating: 0.25Grms (3~500Hz) Z-axis • Non-operating: 1.0Grms (3~500Hz) Z-axis
Shock Protection	• Operating: 20G/11ms, Z/Y/Z axis, each axis 3 times • Non-Operating: 40G/ 11ms, Z/Y/Z axis, each axis 3 times

All specifications are subject to change without prior notice.

1.5 Product View

Front View



No.	Name	Description
1	LCM Display with 4 buttons	N/A
2	Reset Button	Press and hold for system reset
3	LED Indicators	From top to bottom: Status-HDD-Power • Status Amber: N/A Red: System failure / Off: System operating • HDD Flashing green: Storage in use / Off: Storage not active • Power Green: Device is on / Off: Device is off
4	Console Port	N/A
5	2x USB 3.0 Ports	N/A
6	4x 2.5Gbe RJ45 ports	Sequence: left to right Eth1~4 • Left LAN LED -Speed Orange: Operating at highest speed 2.5G Green: Not at full speed 100Mbps • Right LAN LED -Action/Link Green Static: Good linkage Green flashing: Data transmitting Off: No link established • Bypass LAN3/4 Red: Bypass active / Off: Bypass disabled
7	4x 1Gbe SFP ports 2x 10Gbe SFP+	SFP/SFP+ • Left LED -Speed SFP: Orange: operating at 1Gbps Green: Not at full speed SFP+ Orange: operating at 10Gbps Green: Not at full speed • Right LED -Action/Link Green flashing: Data transmitting Off: No link established
8	Network Module	1x PCIe Gen5 (x8)

Oblique View




1+1 Redundant PSU




Single PSU

Rear View

- Single Power Supply Unit




- Redundant Power Supply Unit




No.	Name	Description
1	Expansion Card Slot	1x PCIe Gen5 (x8)
2	Power Button	ATX mode
3	System Fans	N/A
4	Power Supply Units (Single / Redundant)	• 2 AC 100~240V, 50-60Hz, full range 600W 1+1 Redundant Power Supply • 2 AC 100~240V, 50-60Hz, full range 450W 1+1 Redundant Power Supply • 1 AC 100~240V, 47-63Hz, full range 500W Single Power Supply

1.6 Dimensions

INA3608



FML-900G-MB-3606



Chapter 2

Hardware Configuration


The information provided in this chapter includes:

- Configuration inside
- Desktop Installation
- Rack Mount Installation
- System Installation
- Network Module Installation
- Redundant Power Supply Unit
- Memory Module Installation
- HDD Installation and Replacement
- M.2 Card Installation/Replacement

2.1 Installations

2.1.1 Configuration inside

Refer to the figure below for the internal areas to install additional 2.5" HDD/SSD, NIC modules, and expansion card. Area A supports expansion cards. Area B accommodates optional NIC module. Area C supports one 2.5" HDD/SSD.



This device can be placed on a flat surface or mounted in any standard 19inch rack unit with the provided mounting rails.

2.1.2 Desktop Installation

- Place the device on a flat, clean and stable surface.



2.1.3 Rack Mount Installation

Caution

The rack must be stabilized before sliding the unit out for servicing.

Failure to stabilize may cause the rack to tip over.

Electrostatic discharge (ESD) can damage your equipment.

To avoid personal injury or damage to the unit, it is recommended that two or more people install the unit into the rack.

Do not place heavy objects on the unit.

Rack Precautions

- Ensure the leveling jacks on the bottom of the rack are fully extended to the floor with the full weight of the rack resting on the jacks.
- For single rack installation, stabilizers should be attached to the rack.
- For multiple rack installations, the racks should be coupled together.
- Ensure the rack is stable before extending a component from the rack.
- Only extend one component at a time; extending two or more simultaneously may cause the rack to become unstable.


2.1.4 System Installation

For installation or replacement of the memory modules, HDD/SSD, or other internal components, you need to disassemble the device cover first by loosening 6 screws as indicated below.



2.1.5 Network Module

Release the two screws of the network module and pull it out carefully as shown below for replacement and installation.



2.1.6 Redundant Power Supply Unit


If you need to install or replace a redundant power supply unit, push the latch inwards first. Grasp the handle, pull the PSU out carefully and replace it with a new one.



2.1.7 Memory Module

If you need to install or replace a memory module, follow the instructions below after you remove the device cover.


1. Locate the memory slots in the device.



2. Press the ejector tab of the memory slot down and outwards with your fingertips.




3. Hold the memory module and align the key of the module with that on the memory slot.
4. Gently push the module in an upright position until the ejector tabs of the memory slot close to hold the module in place when the module touches the bottom of the slot.




5. To remove the module, press the ejector tabs outwards with your fingertips to eject the module.

2.1.8 HDD Installation and Replacement


After removing the device cover, locate the HDD as shown below (marked in yellow).



Remove screws indicated below to uninstall the HDD from the bottom chassis.




Once the HDD tray has been removed, unfasten the screws (as shown by the circles and arrows) to uninstall the HDD from the tray.




Replace the HDD tray back to its original location after installation/replacement/removal of the HDD.

2.1.9 M.2 Card Installation/Replacement



1. Locate the M.2 slot inside the device.
2. Align the key of the M.2 card to the interface, and insert the card slantwise.
3. Push the M.2 card down and fix it with the an M3 screw.




2.2 Setting the Jumpers







Set up and configure your device by using jumpers for various settings and features according to your needs and applications. Contact your supplier if you have doubts about the best configuration for your use.

2.3.1 How to Set Jumpers

Jumpers are short-length conductors consisting of several metal pins with a non-conductive base mounted on the circuit board. Jumper caps are used to have the functions and features enabled or disabled. If a jumper has 3 pins, shorting either PIN1 to PIN2 or PIN2 to PIN3 will enable the desired function or feature.




Refer to the illustration below to set jumpers.

Pin closed	Oblique view	Jumper Settings
Open		 1 2 3
1-2		 1 2 3
2-3		 1 2 3

- Closed: Jumper cap encased in pins (turned On).
- Open: Jumper cap removed from pins (turned Off).

2.3 Jumper & Connector Locations on Motherboard


Motherboard: FML-900G-MB-3606




2.4 Jumpers Quick Reference

Jumper	Function
JP1	M.2 PCIE / M.2 Select
JP3	Clear ME Register
JP4	Flash Security
JP5	Clear CMOS Content
JP6	SATA DOM Power Select
JP7	AT & ATX Mode
JP9	PM Bus Port
SW1	System Reset
SW2	NMI (Non-Maskable Interrupt)

2.4.1 JP1: M.2 PCIE / M.2 Select




2.4.2 JP3: Clear ME Register




Function	Pin closed	Setting
Save ME RTC Register (default)	1-2	1
Clear ME RTC Register	2-3	1

2.4.3 JP4: Flash Security




Function	Pin closed	Setting
Disabled (default)	1-2	1
Enabled	2-3	1

2.4.4 JP5: Clear CMOS Content




Function	Pin closed	Setting
Save CMOS (default)	1-2	1
Clear CMOS	2-3	1

2.4.5 JP6: SATA DOM Power Select




Function	Pin closed	Setting
5V (default)	1-2	1
Ground	2-3	1

2.4.6 JP7: AT & ATX Mode




Function	Pin closed	Setting
ATX (default)	1-2	1
AT	2-3	1


2.4.7 JP9:



2.4.8 SW1: System Reset




2.4.9 SW2: NMI (Non-Maskable Interrupt)




2.5 Connectors Quick Reference

Connector	Function
BT1	Battery (CR2032)
CN1	Display Port
CN2, CN3, CN6	SATA Power Connector
CN4	SATA DOM Port
CN5, CN7	SATA III Port
CN11	LCM Connector
FAN1, FAN2, FAN3, FAN4	Fan Power Connector
J1, J13	External Power Switch Connector
J2	Factory Use Only
J3	M.2 M2280 Slot
J4, J5	DDR5 Memory Slot
J11	MINI_SAS_LED#
J12	Mini SAS Connector
J14, J6	ATX Power Connector
PCIE1, PCIE2	PCIE Connector
U12	CPU Slot


2.6.1 BT1: Battery (CR2032)




2.6.2 CN1: Display Port




2.6.3 CN2, CN3, CN6: SATA Power Connector




2.6.4 CN4: SATA DOM Port




2.6.5 CN5, CN7: SATA III Port




2.6.6 CN11: LCM Connector




2.6.7 FAN1, FAN2, FAN3, FAN4: Fan Power Connector




2.6.8 J1, J13: External Power Switch Connector




2.6.9 J2: Factory Use Only




2.6.10 J3: .2 M2280 Slot




2.6.11 J4, J5: DDR5 Memory Slot




2.6.12 J11: MINI_SAS_LED#




2.6.13 J12: Mini SAS Connector




2.6.14 J14, J6: ATX Power Connector



2.6.15 PCIE1, PCIE2: PCIe Connector



2.6.16 U12: CPU Slot



Chapter 3

BIOS Setup

This chapter describes the different settings available in the AMI BIOS that comes with the board. The topics covered in this chapter are as follows:

- Main Settings
- Advanced Settings
- Chipset Settings
- Security Settings
- Boot Settings
- Save & Exit

3.1 Introduction

The BIOS (Basic Input/Output System) installed in the ROM of your computer system supports Intel® processors. The BIOS provides critical low-level support for standard devices such as disk drives, serial ports and parallel ports. It also provides password protection as well as special support for detailed fine-tuning of the chipset controlling the entire system.

3.2 BIOS Setup

The BIOS provides a Setup utility program for specifying the system configurations and settings. The BIOS ROM of the system stores the Setup utility. When you turn on the computer, the BIOS is immediately activated. Pressing the key immediately upon startup allows you to enter the Setup utility.. If you don't press the key in time, POST (Power On Self Test) will continue with its test routines, thus preventing you from invoking the Setup.

If you still need to enter Setup, restart the system by pressing the "Reset" button or simultaneously pressing the <Ctrl>, <Alt> and <Delete> keys. You can also restart by turning the system Off and back On again.

The following message will appear on the screen:

```
Press <DEL> to Enter Setup
```

In general, press the arrow keys to highlight items, <Enter> to select, the <PgUp> and <PgDn> keys to change entries, <F1> for help, and <Esc> to quit.

When you enter the BIOS Setup utility, the *Main Menu* screen will appear on the screen. The Main Menu allows you to select from various setup functions and exit choices.

Warning: It is strongly recommended that you avoid making any changes to the chipset defaults.

These defaults have been carefully chosen by both AMI and your system manufacturer to provide the absolute maximum performance and reliability. Changing the defaults could make the system unstable and crash in some cases.

3.3 Main Settings

In the main settings section, the BIOS version and system memory information are shown. It also allows you to configure the date and time settings.

BIOS Setting	Description
System Date	Sets the date. Use the <Tab> key to switch between the date elements.
System Time	Set the time. Use the <Tab> key to switch between the time elements.

3.4 Advanced Settings

This section allows you to configure, improve your system and allows you to set up some system features according to your preference. Settings in this section covers:

- Trusted Computing
- ACPI Settings
- NCT55230 Super IO Configuration
- NCT78940 HW Monitor
- Serial Port Console Redirection
- PCI Subsystem Settings
- USB Configuration
- NVME Configuration



3.4.1 Trusted Computing



BIOS Setting	Description
Security Device Support	Enables / Disables BIOS support for security device. O.S. will not show security device. TCG EFI protocol and INT1A interface will not be available.
Pending operation	Schedule an operation for the security device. Note: Your computer will reboot during restart in order to change the state of security device.

3.4.2 ACPI Settings




BIOS Setting	Description
Enable ACPI Auto Configuration	Enables / Disables BIOS ACPI Auto Configuration.
Enable Hibernation	Enables / Disables system ability to hibernate (OS/S4 Sleep State). This option may not be effective with some operating systems.


3.4.3 NCT552130 Settings



BIOS Setting	Description
Serial Port Configuration	Sets parameters of Serial Ports. Enables / Disables the serial port and select an optimal setting for the Super IO device.




3.4.4 NCT78940 HW Monitor




BIOS Setting	Description
Smart Fan Control	Disable or setting smart fan control start up temperature.
Temperatures / Voltages	These fields are the parameters of the hardware monitoring function feature of the motherboard. The values are read-only values as monitored by the system and show the PC health status.

3.4.5 Serial Port Console Redirection



BIOS Setting	Description
Console Redirection	Allows you to enable or disable the console redirection feature.
Console Redirection Settings	These items become configurable only when you enable the Console Redirection item. The settings specify how the host computer and the remote computer (which the user is using) will exchange data. Both computers should have the same or compatible settings.




BIOS Setting	Description
Terminal Type	Emulation: ANSI: Extended ASCII charset. VT100: ASCII charset. VT100+: Extends VT100 to support color, function keys, etc. VT-UTF8: Uses UTF8 encoding to map Unicode.
Bits per second	Selects serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds. Options: 9600, 19200, 38400, 57600, 115200
Data Bits	Options: 7, 8
Parity	A parity bit can be sent with the data bits to detect some transmission errors. Even: parity bit is 0 if the num of 1's in the data bits is even. Options: None, Even, Odd, Mark, Space
Stop Bits	Stop bits indicate the end of a serial data packet. (A start bit indicates the beginning). The standard setting is 1 stop bit. Options: 1, 2

BIOS Setting	Description
Flow Control	Flow control can prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a “stop” signal can be sent to stop the data flow. Options: None, Hardware RTS/CTS
VT-VTF8 Combo Key Support	Enables / Disables VT-UTFB combination key support for ANSI/VT100 terminals.
Recorder Mode	With this mode enabled, only text will be sent. This is to capture terminal data.
Resolution 100x31	Enables / Disables extended terminal resolution.
Putty Key pad	Select FunctionKey and keyPad on Putty. Options: VT100, LINUX, XTERMR6, SC0, ESCN, VT400




BIOS Setting	Description
Legacy Console Redirection Port	Allows you to select a COM port to display redirection of Legacy OS and Legacy OPRM Messages. Options: [COM1] [COM2]
Redirection COM Port	Select a COM port to display redirection of Legacy OS and Legacy OPRM Messages.
Redirection After POST	This setting allows you to specify if Bootloader is selected than Legacy console redirection Default setting: Always Enable

3.4.6 PCI Subsystem Settings




BIOS Setting	Description
Above 4G Decoding	This item enables or disables 64bit capable Devices to be Decoded in Above 4G Address Space (Only if System Supports 64bit PCI Decoding).
SR-IOV Support	This item if system has SR-IOV capable PCIe Devices, this option enables or disables Single Root IO Virtualization Support.
BME DMA Mitigation	This item Re-enable Bus Master Attribute disabled during Pci enumeration for PCI Bridges after SMM Locked.

3.4.7 USB Configuration



BIOS Setting	Description
Legacy USB Support	• Enable: Enables Legacy USB Support. • Auto: Disables legacy support if no USB devices are connected. • Disable: Keeps USB devices available only for EFI applications.
XHCI Hand-off	This is a workaround for OSEs without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.
USB Mass Storage Driver Support	Enables / Disables the support for USB mass storage driver.
USB Transfer time-out	The time-out value for Control, Bulk, and Interrupt transfers.
Device reset time-out	Seconds of delaying execution of start unit command to USB mass storage device.
Device power-up delay	The maximum time the device will take before it properly reports itself to the Host Controller. "Auto" uses default value for a Root port it is 100ms. But for a Hub port, the delay is taken from Hub descriptor.

3.4.8 NVMe Configuration



3.5 Platform Configuration

This section allows you to configure PCH SATA and eSATA settings.




BIOS Setting	Description
PCH SATA and eSATA Configuration	SATA device options and settings
Wake on LAN Enable	Enables / Disables integrated LAN to wake the system.
Restore AC Power Loss	Select AC power state when power is re-applied after a power failure. Options: Power Off, Power On, Last State.




3.6 Socket Configuration


This section is for processor configuration. It displays and provides options to change the processor settings.



3.7 Server Management



BIOS Setting	Description
BMC Support	Enables / Disables interfaces to communicate with BMC.
Wait For BMC	Wait For BMC reponse for specified time out.
BMC SOL Function	Enables / Disables BMC SOL function. Enable: will inactive and clear IRQ and IObase of UART1. Disable: keep original IRQ, IObase and active UART1
System Event Log	Allows you to configure the settings for system event log.
BMC self test log	Allows you to configure when to erase the log.
BMC Network Configuration	Configures BMC network parameters.




BIOS Setting	Description
SEL Components	Enables / Disables all features of system event logging during boot.
Erase SEL	Allows you to choose options for erasing SEL. Options: No, Yes on next reset, Yes on every reset
When SEL is Full	Allows you to choose options for reactions to a full SEL. Options: Do nothing, Erase immediately
Log EFI Status Codes	Disables the logging of EFI status codes or log only error code or only progress code or both. Options: Disabled, Both, Error code, Progress code

3.8 Security Settings




BIOS Setting	Description
Administrator Password	Sets an administrator password for the setup utility.
User Password	Sets a user password.

3.9 Boot Settings



BIOS Setting	Description
Setup Prompt Timeout	Number of seconds to wait for setup activation key. 65535 (0xFFFF) means indefinite waiting.
Bootup NumLock State	Turns on/off the keyboard NumLock state.
Quiet Boot	Enables / Disables Quiet Boot option.
Network	Enables / Disables Network
Boot Option Priorities	Sets the system boot order.

3.10 Save & Exit Settings



BIOS Setting	Description
Save Changes and Exit	Exits system setup after saving the changes.
Save Changes and Reset	Resets the system after saving the changes.
Discard Changes and Reset	Resets system setup without saving any changes.
Restore Defaults	Restores / Loads defaults values for all the setup options.

3.11 Server Management Settings



BIOS Setting	Description
BMC network configuration: LAN Channel 1	
Configuration Address source	Select to configure LAN channel parameters statically or dynamically (DHCP). Do nothing option will not modify any BMC network parameters during BIOS phase. Options available: Unspecified / Static / DynamicBmcDhcp. Default setting is DynamicBmcDhcp
Station IP address	Displays IP Address information
Subnet mask	Displays Subnet Mask information Please note that the IP address must be in three digitals for example 192.168.000.001.
Router IP address	Displays the Router IP Address information

This page is intentionally left blank.